

SPA-QUICK START





Step 1

Fill Spa using the Carbon Filter that was provided in the "CalSalt" Filtration Kit.

Step 2

Turn ON Spa and set "CalSalt" Filtration Chlorine time to Zero (0). See manual for Control Panel settings configurations.

Step 3

Balance the Spa water levels (Use Test strips and Chemicals provided in Kit).

• Total Alkalinity, pH, Total Hardness, Total Chlorine.

PREFERRED LEVELS	FACTORS	FACTORS	
1900 - 2000 ppm	Salt	and the second	
7.2-7.8	PH	all the	
3.0-5.0	Free Chlorine	10 Frank	
100-120 ppm	Total Alkalinity	Real Providence	
150-200 ppm	Calcium Hardness		

Step 4

Take a sample of the water with a cup. Check Salt level with Salt Strips provided in Kit. Refer to Salt Table below to know the amount of salt required. The amount of Salt needed to achieve 1900 ppm - 2000 ppm level on the spa is on the table.

Spa Size in	Salinity (ppm) measured in Spa				
Gallons	0 ppm	500 ppm	1000 ppm	1500 ppm	
200 - 300 Gallons 5 ft Spa	Add 2.5 lbs	Add 2.3 lbs	Add 1.25 lbs	Add 1 lb	
400 - 450 Gallons 7 ft Spa	Add 7.4 lbs	Add 5.7 lbs	Add 4 lbs	Add 2.3 lbs	
400 - 450 Gallons 8 ft Spa	Add 9.4 lbs	Add 7.4 lbs	Add 5.3 lbs	Add 3.2 lbs	
750 - 850 Gallons 11 ft Spa	Add 13.3 lbs	Add 11 lbs	Add 8.7 lbs	Add 6.4 lbs	
1550 - 1650 Gallons 13 ft Swim Spa	Add 29 lbs	Add 26.5 lbs	Add 24 lbs	Add 21.5 lbs	

Step 5

After water chemistry is adequately balanced, turn ON Pump to Hi-Speed and add "CalSalt" bags (Reference: Step.4). Wait for the Salt to dissolve. (At least 1 hour)

Step 6

Remember to wait at least an hour before adjusting the Chlorine time to the recommended hour setup by Spa size.

Step 7

Proceed by adjusting the setting on Chlorine time Control Panel depending on spa size. EX. (Spa Size / Chlorine Time) Subsequently 5 ft. / 2 hours; 7 ft. / 3 hours; 8 ft. / 4 hours; 13 ft. / 10 hours.

Step 8

After the 2 Days of supervising the changes of Spa levels use the Test Strips to see if any adjustments are needed.

Step 9

Monitor every 3 to 4 days with recommended procedures.

Step 10

Routine check-ups are important to achieve desired water levels.